



C11-EN-N 06/2021

# **Table of content**

# Table of content

Declaration of performance	4
Product presentation CR120	5
Range and dimensions CR120	5
Variant CR120-L500	6
Range and dimensions CR120-L500	6
Variant CR120-1S	6
Range and dimensions CR120-1S	7
Variant CR120-1S-L500	7
Range and dimensions CR120-1S-L500	8
Evolution - kits	8
Options - at the time of order	11
Storage and handling	12
Installation	12
Installation at a minimal distance from another damper or from an adjacent supporting construction	13
Installation in a rigid wall	14
Installation in rigid floor	16
Installation in flexible wall (metal stud gypsum plasterboard wall)	18
Installation in flexible wall (metal stud gypsum plasterboard wall), sealing with gypsum	20
Installation in flexible wall (metal stud gypsum plasterboard wall), sealing with mortar	22
Installation in gypsum block wall	24
Installation in flexible and rigid wall, sealing with rigid rock wool boards with coating	26
Installation in rigid floor, sealing with rigid rock wool boards with coating	29
Installation remote from the wall, sealing and insulation with rigid rock wool boards with coating Installation remote from the wall, sealing with mortar and insulation with rigid rock wool boards with coating	31 34
Installation remote from the wall + GEOFLAM	36
Installation in rigid wall with collar for surface-mount 1s	39
Installation in flexible wall with collar for surface-mount 1s	40
Inspection of the damper	41
Operation and mechanisms	42
Electrical connection	46
Weights	48
Selection data	49
Example	49
Correction factor ΔL	50
Sample order	51
Approvals and certificates	51

3

## **Explanation of the abbreviations and pictograms**

Wn = nominal width	E.TELE = power supply magnet	Sn = free air passage
Hn = nominal height	E.ALIM = power supply motor	$\zeta$ [-] = pressure loss coefficient
Dn = nominal diameter	V = volt	Q = airflow
E = integrity	W = watt	$\Delta P = static pressure drop$
I = thermal insulation	Auto = automatic	v = air speed in the duct
S = smoke leakage	Tele = remote controlled	Lwa = A-weighted sound power level
Pa = pascal	Pnom = nominal capacity	Lw oct = sound power level per octave
ve = vertical wall penetration	Pmax = maximum capacity	midband
ho = horizontal floor penetration	GKB (type A) / GKF (type F): "GKB"	dB(A) = A-weighted decibel value
o -> i = meets the criteria from the outside	stands for standard plasterboards (type	$\Delta L = correction factor$
(o) to the inside (i)	A according to EN 520) while "GKF"	
i <-> o = fire side not important	plasterboards offer a higher fire resistance	
V AC = Volt alternating current	for a similar plate thickness (type F	
V DC = Volt direct current	according to EN 520)	
	Cal-Sil = calcium silicate	
	OP = option (delivered with the product)	
	KIT = kit (delivered separately for repair or	
	upgrade)	
	PG = connection flange to the duct	

	higher net building volume through compact size	X	optimal acoustic performance
	optimal free air passage and minimal pressure loss		minimal distance allowed
EN 1751 C	air-tightness class C according to EN1751	Cy	Hygiene certificate (www.HYG.de)
	suitable for built-in installation		suitable for installation remote from the wall
BASTA OK	sealing with fire resistant stone wool boards allowed, also for asymmetric opening	$\bigcirc$	fast installation

# **DECLARATION OF PERFORMANCE**

GE\_D0P\_Rf-t\_C11\_EN = L-06/2021

4

2. Intended use/es: 3. Manufacturer: 4. System/s of AVCP:						
3. Manufacturer: 4. Svstem/s of AVCP:			Circular fire damper to be used in continuction with partitions to maintain fire compartments in heating, ventilating and air conditioning installations	h partitions to maintain fire compartme	ents in heating ventilating and air conditioning i	nstallations.
<ol> <li>Manuracturer:</li> <li>4. Svstem/s of AVCP:</li> </ol>					בווט ווו ווכמנוווט, אכוונוומנוווט מווט מוו כטווטונוטווווט ו	-cilonaliario
4. Svstem/s of AVCP:			kt-lechnologies NV, Lange Ambachtstraat 40, b-9860 Oosterzele	860 Oosterzele		
			System 1			
5. Harmonised standard / European Assessment Documer notified body; certificate of constancy of performance:	uropean Assessment of constancy of perfu	<ol> <li>Harmonised standard / European Assessment Document; notified body / European Technical Assessment, Technical Assessment Body, notified body; certificate of constancy of performance:</li> </ol>	essment Body, EN 15650:2010, BCCA with identification number 0749; BCCA-0749-CPR-BC1-606-0464-15650.02-2517	0749; BCCA-0749-CPR-BC1-606-0464-1	5650.02-2517	
6. Declared performance according to EN 15650:2010	cording to EN 15650:	:2010	(Fire resistance according to EN 1366-2 and classifications according to EN 13501-3)	fications according to EN 13501-3)		
Essential characteristics					Performance	
Range	Wall type	Wall	Sealing	Installation	┢	
Ø 100-315 mm	Rigid wall	Reinforced concrete ≥ 110 mm	Mortar / Gypsum	-	_	
	I	Aerated concrete ≥ 100 mm	Gypsum		El 120 (v <sub>e</sub> i ↔ o) S- (500 Pa)	1
	-		Mortar	-	El 120 (v <sub>e</sub> i ↔ o) S - (300 Pa)	1
	-		Stone wool + coating $\ge 140 \text{ kg/m}^3$ + coated casing	-	El 120 (v <sub>e</sub> i ↔ o) S - (300 Pa)	1
			Stone wool + coating $\ge 140 \text{ kg/m}^3$	1	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)	
			Stone wool Mulcol Multimastic SP + coating	1	El 60 (v <sub>e</sub> i ↔ o) S - (300 Pa)	
			Galvanised duct + stone wool + coating $\ge 140 \text{ kg/m}^3 2x50 \text{ mm}$	2	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)	
			Galvanised duct + stone wool + coating $\ge 140 \text{ kg/m}^3 2x50 \text{ mm} + \text{mortar}$		El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)	1
			Galvanised duct + GEOFLAM® F 45 mm + mortar	2	El 120 (v <sub>e</sub> i ↔ o) S - (500 Pa)	1
			Galvanised duct + GEOFLAM® Light 35 mm + mortar	2	El 120 (v <sub>e</sub> i ↔ o) S - (500 Pa)	1
	Rigid floor	Reinforced concrete ≥ 150 mm	Mortar	m	El 120 (h₀ i ↔ o) S - (500 Pa)	1
		Aerated concrete ≥ 100 mm	Mortar	m	El 90 (h₀ i ↔ o) S - (500 Pa)	
		Aerated concrete ≥ 150 mm	Stone wool + coating $\ge 140 \text{ kg/m}^3$ + coated casing	m	El 120 (h₀ i ↔ o) S - (300 Pa)	1
			Stone wool + coating ≥ 140 kg/m <sup>3</sup>	m	El 90 (h₀ i ↔ o) S - (300 Pa)	1
	Flexible wall	Metal studs gypsum plasterboard Type A (EN 520) ≥ 100 mm	Gypsum	-	El 60 (v <sub>e</sub> i ↔ o) S - (500 Pa)	1
			Stone wool + coating $\ge 140 \text{ kg/m}^3$	1	El 60 (v <sub>e</sub> i ↔ o) S - (300 Pa)	н
		Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Gypsum	-	El 90 (v <sub>e</sub> i ↔ o) S - (500 Pa)	
			Mortar	-	El 120 ( $v_e$ i $\leftrightarrow$ o) S - (300 Pa)	ioni: EN 1
			Stone wool + coating $\ge 140 \text{ kg/m}^3$ + coated casing	-	El 120 ( $v_e$ i $\leftrightarrow$ o) S - (300 Pa)	
			Stone wool + coating $\ge 140 \text{ kg/m}^3$	-	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)	
		Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Stone wool Mulcol Multimastic SP + coating	-	El 60 (v <sub>e</sub> i ↔ o) S - (300 Pa)	
			Galvanised duct + stone wool + coating $\ge 140 \text{ kg/m}^3 2x50 \text{ mm}$	2	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)	rd 
		Gypsum blocks ≥ 70 mm	Block glue	-	El 120 (v <sub>e</sub> i ↔ o) S - (500 Pa)	
Ø 100-250 mm	Flexible wall	Metal studs gypsum plasterboard Type A (EN 520) ≥ 100 mm	Stone wool ≥ 40 kg/m <sup>3</sup> + cover plates	-	El 60 (v <sub>e</sub> i ↔ o) S - (500 Pa)	1
CR120-15 Ø 100-315 mm	Rigid wall	Aerated concrete ≥ 100 mm	Not applicable	4	El 120 ( $v_e$ i $\leftrightarrow$ o) S - (500 Pa)	1
	Flexible wall	Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 - ≤ 125 mm	Not applicable	4	El 120 ( $v_e$ i $\leftrightarrow$ o) S - (500 Pa)	1
<ol> <li>Type of installation: built-in, 0-360°. Minimal distances autho- rised with axis till 45°.</li> </ol>	on: built-in, distances autho- l 45°.	300     4.45     4.42     3.00m     2     Type of installation: remote from from the second se	Type of installation: remote from the wall, $0.180^{\circ}$ . Minimal distances $\Theta \Theta$ authorised	Type of in stallation: built-in, 0-360°. Minimal distances authorised.		
4 Type of installation: surface- mounted, 0/180°. Minimal distances authorised.	on: surface- . Minimal ised.					1
Nominal activation conditions/sensitivity:	ns/sensitivity:		Pass			1
Response delay (response time): closure time	me): closure time		Pass MFUS - 50 cvcles; MMAG - 300 cvcles; B(L)F(T) - 10000 cvcles; BFL(T) - 10000 cvcles; ONE - 10000 cvcles; UNIO - 10000	00 cvcles: BFL(T) - 10000 cvcles: ONE - 1	0000 cvcles: ONE-X - 10000 cvcles: UNIO - 10000	
Operational reliability: cycling	ы Б		cycles			
Durability of response delay: Durability of operational reliability:	: ability:		Pass			
Protection against corrosion according to EN 60068-2-52:	according to EN 600	068-2-52:	Pass			
Damper casing leakage according to EN 1751:	rding to EN 1751:		≥ class C			
The performance of the prot performance is issued, in acc	uct identified above ordance with Regulat	The performance of the product identified above is in conformity with the set of declared performance/s. This declaration of performance is issued, in accordance with Regulation (EU) No 305/2011, under the sole responsibility of the manufacturer identi-	Signed	Signed for and on behalf of the manufacturer by: Mathieu Steenland, Technical Manager		(
fied above.	'n	-		Oosterzele, 06/2021	Ath with	

### **Product presentation CR120**

Optimised circular fire damper with a fire resistance up to 120 minutes. A minimal pressure loss is guaranteed thanks to the thin blade, the fusible link aligned with the blade, and the transmission located outside the tunnel. The damper is available in small diameters (starting from 100 mm). Its galvanised steel tunnel contributes to the light weight of the damper.


Fire dampers are installed where air ducts penetrate fire-resistant compartment walls. Their role is to restore the fire resistance grade of the penetrated wall and to prevent smoke propagation. Fire dampers are distinguished by their degree of fire resistance, by their aeraulic properties as well as by their installation ease. Rf-Technologies' fire dampers are all CE marked. They can be equipped with various types of mechanisms depending on the specific needs linked to the project or to the local regulations.

- easy to install
- ☑ optimal free air passage and minimal pressure loss
- ☑ optimal acoustic performance
- $\ensuremath{\,^{\bigtriangledown}}$  higher net building volume through compact size
- ☑ air-tightness class C according to EN1751
- suitable for built-in installation
- suitable for installation remote from the wall
- minimal distance allowed
- suitable for rigid wall, rigid floor and light wall (metal stud gypsum plasterboard wall)
- sealing with fire resistant stone wool boards allowed, also for asymmetric opening
- tested according to EN 1366-2 up to 500 Pa
- operating mechanism outside the wall
- maintenance-free
- for indoor use
- operating temperature: max. 50°C
- Hygiene certificate (www.HYG.de)
- 1. casing in galvanised steel
- 2. damper blade
- 3. operating mechanism
- 4. rubber sealing ring
- 5. intumescent strip
- 6. base plate for thermo-electrical fuse
- 7. positioning plate
- 8. sealing ring for damper blade
- 9. fusible link
- 10.product identification

### **Range and dimensions CR120**

### ØDn Imm] 100 125 150 160 180 200 250 300 315

### Exceeding damper blade: 20 mm for ØDn 315 mm







### Variant CR120-L500


CR120 damper with a tunnel casing extension at the wall side to facilitate the connection to the duct when the supporting construction is thicker than 100 mm.

- 1. casing in galvanised steel
- 2. damper blade
- 3. operating mechanism
- 4. rubber sealing ring
- 5. intumescent strip
- 6. base plate for thermo-electrical fuse
- 7. positioning plate
- 8. sealing ring for damper blade
- 9. fusible link
- 10.product identification

### **Range and dimensions CR120-L500**



### ØDn Imml | 100 | 125 | 150 | 160 | 180 | 200 | 250 | 300 | 315 |



### Variant CR120-1S


Surface mounted circular fire damper with a fire resistance of 120 minutes. The surface mounting ensures a fast (dry) installation. Its thin blade, the fusible link aligned with the blade, and the transmission located outside the tunnel guarantee a minimum pressure loss. The damper is available in small diameters (startingfrom 100 mm).

- ☑ no specific tools, no sealing required
- ✓ fast installation
- ☑ air-tightness class C according to EN1751
- suitable for surface-mount in rigid wall and light wall (metal stud gypsum plasterboard wall)
- not available in diameter 150, 180 and 300 mm
- minimal distance allowed
- 1. fire damper
- 2. upper mounting collar
- 3. lower mounting collar
- 4. graphite strip
- 5. sealing cold smoke
- 6. tape + graphite strip

### **Range and dimensions CR120-1S**

### ØDn Imm] | 100 | 125 | 160 | 200 | 250 | 315 |

Exceeding damper blade: 20 mm for ØDn 315 mm





ØDn	<b>1</b> s	Ød	ø
100	279	160	180
125	299	180	200
160	339	220	240
200	374	255	275
250	419	300	320
315	474	355	375








### Variant CR120-1S-L500

CR120-1S damper with a tunnel casing extension at the wall side to facilitate the connection to the duct when the supporting construction is thicker than 100 mm.

- ☑ no specific tools, no sealing required
- fast installation
- ☑ air-tightness class C according to EN1751
- suitable for surface-mount in rigid wall and light wall (metal stud gypsum plasterboard wall)
- not available in diameter 150, 180 and 300 mm
- minimal distance allowed
- 1. fire damper
- 2. upper mounting collar
- 3. lower mounting collar
- 4. graphite strip
- 5. sealing cold smoke
- 6. tape + graphite strip


### Range and dimensions CR120-1S-L500

### ØDn Imm] | 100 | 125 | 160 | 200 | 250 | 315 |



ØDn	<b>1</b> s	Ød	øP
100	279	160	180
125	299	180	200
160	339	220	240
200	374	255	275
250	419	300	320
315	474	355	375





	MFUS	ONE (X)	BFL(T)
P	72	80	63
Q	123	136	100
Z	70	75	58





Evolution - kits

## **Evolution - kits**

	KITS MFUS	Automatic unlocking mechanism with fusible link
	KITS ONE T 24 FDCB	Spring return actuator ONE 24V (with fusible link T) + bipolar beginning- and end-of- range switch
	KITS ONE T 24 FDCU	Spring return actuator ONE 24V (with fusible link T) + unipolar beginning- and end-of- range switch
	KITS ONE T 230 FDCU	Spring return actuator ONE 230V (with fusible link T) + unipolar beginning- and end-of-range switch
	KITS ONE T 230 FDCB	Spring return actuator ONE 230V (with fusible link T) + bipolar beginning- and end-of- range switch
	KIT ONE-X 24	Spring return actuator ONE-X 24V (with fusible link T)
	KIT ONE-X 230	Spring return actuator ONE-X 230V (with fusible link T)
·····	KITS BFL24	Spring return actuator BFL 24V
· ····	KITS BFL230	Spring return actuator BFL 230V

# Evolution - kits

······································	KITS BFL24-ST	Spring return actuator BFL 24V with plug (ST)
	KITS BFLT24	Spring return actuator BFL 24V with thermo-electric fuse (T)
	KITS BFLT230	Spring return actuator BFL 230V with thermo-electric fuse (T)
	KITS BFLT24-ST	Spring return actuator BFL 24V with thermo-electric fuse (T) and plug (ST)
	KITS BFN24	Spring return actuator BFN 24V (BFN kits must be used instead of BFL kits for fire dampers produced before 1/7/2015)
	KITS FDCU MFUS(P)	Limit switch 'open/closed'
5 50	KITS SN2 BFL/BFN	Auxiliary limit switch 'open/closed'
Ŷ	KITS ZBAT 72	Black spare part for thermo-electric fuse for BFLT/BFNT
	KITS FUS 72 MFUS(P)	Fusible link 72°C

	FUS72 ONE	Fusible link 72°C
	MECT	Testbox for mechanisms 24/48 V (magnet, motor, beginning and end of range switches)
	EPP CR60/120	Kit with 4 cover plates (gypsum plasterboard 12.5 mm) for CR60, CR120 in light wall.
0	INSPECAM	Sturdy digital endoscope for the internal inspection of fire dampers through an optional inspection opening. The endoscope features a 1 meter long probe with a diameter of 8,2 mm equipped with a dimmable LED, a removable 4x zoom, a colour LCD monitor 3.5". Photographic capture 3MP and video capture 720P.

## <u> Options - at the time of order</u>

Se	1\$	Collar for circular surface-mount 1s (100-315 mm)
	UL	Inspection opening to visually determine the state and the position of the damper, by using an endoscope.
	ONE-X CN	Connectors for the bus cables and the power cable.

### **Storage and handling**

As this product is a safety element, it should be stored and handled with care.

### Avoid:

- any kind of impact or damage
- contact with water
- deformation of the casing

### It is recommended:


- to unload in a dry area
- not to flip or roll the product to move it
- not to use the damper as a scaffold, working table, etc.
- not to store smaller dampers inside larger ones

### **Installation**

### **General points**


- The installation must comply with the installation manual and the classification report.
- Axis orientation: see the declaration of performance.
- Avoid obstruction of adjoining ducts.
- Product installation: always with closed damper blade.
- Verify if the blade can move freely.
- Please observe safety distances with respect to other construction elements. The operating mechanism must also remain accessible: allow for a clearance of 200 mm around the housing.
- The air tightness class will be maintained if the damper is installed according to the installation manual.
- Rf-t fire dampers are always tested in standardised constructions according to EN 1366-2. The achieved results are valid for similar supporting constructions with a fire resistance, thickness and density equal or superior to the supporting construction used during the test.
- The damper must remain accessible for inspection and maintenance.
- Schedule at least 2 visual checks each year.





Installation at a minimal distance from another damper or from an adjacent supporting construction

2



### 1. Principle


3

1

According to the European test standard, a fire damper must be installed at a minimum distance of 75 mm from an adjacent wall and 200 mm from another damper, unless the solution was tested at a shorter distance.

This range of Rf-t fire dampers has been successfully tested and can be installed in a vertical or horizontal supporting construction, at a distance below the minimum set by the standard.

For circular dampers, the minimal distance is set to 30 mm.



### 2. Certified solution

For the Rf-t fire dampers, the solution consists of the following elements: A: Universal sealing for minimal distance; B: Sealing compliant with existing classifications (Declaration of Performance).

A. Sealing of the opening at the side with minimal distances between damper and wall/ceiling or another fire damper: rigid stone wool panels (150 kg/m<sup>3</sup>) are applied to a depth of min. 400 mm, of which 150 mm on the mechanism side of the wall. On the non-mechanism side of the wall, the stone wool panels must be at least flush with the wall.


The surface of this sealing is set between the axes (centres) of the dampers.

B. Sealing of the rest of the opening according to the existing classifications for the fire damper (Declaration of Performance). This also applies to circular dampers that are mounted at a minimum distance from one another (30 to 200 mm) but at a distance greater than 75 mm from a wall/ceiling. Detailed information for each wall/sealing combination can be found in the respective installation methods.

### 3. Restrictions

The orientation of the blade axis should be horizontal or oriented at a maximum of 45°.

A maximum of 3 circular dampers can be installed at a minimum distance from one another, both vertically and horizontally (with a maximum cluster of 4 dampers). Note: when sealing the opening with panels of fire resistant stone wool, the maximum number of dampers also depends on the maximum "blank seal" allowed for the selected sealing material. Please refer to the manufacturer's instructions for this information.




### Installation in a rigid wall


### The product was tested and approved in:

Range	Wall type		Sealing	Classification
Ø 100-315 mm	Rigid wall	Reinforced concrete $\geq$ 110 mm	Mortar / Gypsum	El 120 ( $v_e i \leftrightarrow o$ ) S - (500 Pa)
Ø 100-315 mm	Rigid wall	Aerated concrete ≥ 100 mm	Gypsum	El 120 ( $v_e i \leftrightarrow o$ ) S - (500 Pa)
Ø 100-315 mm	Rigid wall	Aerated concrete $\geq$ 100 mm	Mortar	El 120 (v <sub>e</sub> i $\leftrightarrow$ o) S - (300 Pa)

2


4






3

1







4. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.



7



5. Make the necessary openings ( $\leq$  Dn + 100 mm) / ( $\leq$  Dn + 80 mm) in the wall.



6. Mount the dampers in the opening.


6

Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.

A Caution: the opening is sealed according to the existing classification (see next point) when:

- 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.

- One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.



7. Seal the rest of the opening with standard mortar or gypsum.


### Installation in rigid floor

### The product was tested and approved in:

Range	Wall type		Sealing	Classification
Ø 100-315 mm	Rigid floor	Reinforced concrete $\geq$ 150 mm	Mortar	El 120 (h <sub>o</sub> i $\leftrightarrow$ o) S - (500 Pa)
Ø 100-315 mm	Rigid floor	Aerated concrete $\geq$ 100 mm	Mortar	El 90 ( $h_o i \leftrightarrow o$ ) S - (500 Pa)


2

4







1




3. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.





4. Make the necessary openings ( $\leq Dn + 80$  mm) in the floor.



5

5. Mount the dampers in the opening. Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the floor) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.

- A Caution: the opening is sealed according to the existing classification (see next point) when:
  - 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.
  - One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.




6

6. Seal the rest of the opening with standard mortar.

### Installation in flexible wall (metal stud gypsum plasterboard wall)


The product was tested and approved in:



5. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.

6. Build the drywall and foresee horizontal and vertical studs around the opening.

In the opening around the dampers (Dn + 50 mm), the void between the gypsum boards is filled with stone wool with a minimum density of 40 kg/m<sup>3</sup>.




7. Mount the dampers in the opening.

7

Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.

- A Caution: the opening is sealed according to the existing classification (see next point) when:
  - 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.
  - One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.



8

8. Apply cover plates (gypsum plasterboards) to finish the surface at both sides.

Seal off the space between the plasterboards with jointfiller.

1

3


### Installation in flexible wall (metal stud gypsum plasterboard wall), sealing with gypsum


The product was tested and approved in:


Range	Wall type		Sealing	Classification
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type A (EN 520) ≥ 100 mm	Gypsum	El 60 (v <sub>e</sub> i $\leftrightarrow$ o) S - (500 Pa)
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Gypsum	El 90 (v <sub>e</sub> i ↔ o) S - (500 Pa)

2

4








3. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.

2x12.5/1x25 mm

4. Build the drywall and foresee horizontal and vertical studs around the opening.

In the opening around the dampers, the void between the gypsum boards is partially filled (up to Dn + 80 mm) with stone wool with a minimum density of  $40 \text{ kg/m}^3$ .



6



6. Seal the rest of the opening with standard gypsum across the entire wall thickness.

5. Mount the dampers in the opening.

Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.


A Caution: the opening is sealed according to the existing classification (see next point) when:

- 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.

- One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.

### Installation in flexible wall (metal stud gypsum plasterboard wall), sealing with mortar

The product was tested and approved in:



3. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.

4. Build the drywall and foresee horizontal and vertical studs around the opening.




5. Mount the dampers in the opening.

Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.

- A Caution: the opening is sealed according to the existing classification (see next point) when:
  - 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.
  - One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.


6



6. Seal the rest of the opening with standard mortar across the entire wall thickness.


### Installation in gypsum block wall

### The product was tested and approved in:



3. The dampers can be installed at a minimum distance from an 4. Make the necessary openings ( $\leq$  Dn + 80 mm) in the wall. adjacent wall or from another damper.






5. Mount the dampers in the opening.

Apply rigid stone wool panels ( $\geq 150 \text{ kg/m}^3$ ) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances. The surface of this sealing is set between the axes (centres) of the dampers.

- A Caution: the opening is sealed according to the existing classification (see next point) when:
  - 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.
  - One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.





6. Seal the rest of the opening with block glue across the entire wall thickness.


Installation in flexible and rigid wall, sealing with rigid rock wool boards with coating


The product was tested and approved in:

Range	Wall type	Walltype		Classification
Ø 100-315 mm	Rigid wall	Aerated concrete $\geq$ 100 mm	Stone wool + coating $\geq$ 140 kg/m <sup>3</sup> + coated casing	El 120 (v <sub>e</sub> i $\leftrightarrow$ o) S - (300 Pa)
Ø 100-315 mm	Rigid wall	Aerated concrete $\geq$ 100 mm	Stone wool + coating $\geq$ 140 kg/m <sup>3</sup>	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type A (EN 520) ≥ 100 mm	Stone wool + coating $\ge 140 \text{ kg/m}^3$	El 60 (v <sub>e</sub> i ↔ o) S - (300 Pa)
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Stone wool + coating $\geq$ 140 kg/m <sup>3</sup> + coated casing	El 120 (v <sub>e</sub> i ↔ o) S - (300 Pa)
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Stone wool + coating $\geq$ 140 kg/m <sup>3</sup>	El 90 (v <sub>e</sub> i ↔ o) S - (300 Pa)
Ø 100-315 mm	Rigid wall	Aerated concrete ≥ 100 mm	Stone wool Mulcol Multimastic SP + coating	El 60 (v <sub>e</sub> i ↔ o) S - (300 Pa)
Ø 100-315 mm	Flexible wall	Metal studs gypsum plasterboard Type F (EN 520) ≥ 100 mm	Stone wool Mulcol Multimastic SP + coating	El 60 (v <sub>e</sub> i $\leftrightarrow$ o) S - (300 Pa)

2

4






2. The opening around the damper is sealed with 2 layers of 50 mm-thick mineral wool panels with fire resistant coating on one side (type PROMASTOP-CB 50 / PROMASTOP-CB/CC 50 / HILTI CFS-CT B / Mulcol Multimastic FB1).


3

1



3. The joints on these 2 layers must be installed staggered and covered all around the edge with coating (type PROMASTOP-E / PROMASTOP-CC / HILTI CFS-S-ACR / Mulcol Multimastic SP).

MULCOL MULTIMASTIC C PROMASTOP F/CC /HILTI CFS-S ACR




5


7


9

5. For El 120 S, the casing of the fire damper must be covered with a layer (> 1 mm) of coating (type PROMASTOP E / PROMASTOP CC / HILTI CFS-CT).



7. The damper does not need to be centered in the opening (with max dimensions fire damper + 600 mm). The maximal distance between the damper and the edge of the opening is 400 mm.







6

8


10



8. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.



10. Build the drywall and foresee horizontal and vertical studs around the opening.Mount the dampers in the opening.




11. Apply rigid stone wool panels ( $\geq$  150 kg/m<sup>3</sup>) to a depth of 400 mm (150 mm on the mechanism side of the wall) to seal the opening at the side with minimal distances.

The surface of this sealing is set between the axes (centres) of the dampers.

A Caution: the opening is sealed according to the existing classification (see next point) when:

- 2 fire dampers are installed at a minimum distance from one another but at a normal distance ( $\geq$  75 mm) from the wall or floor/ceiling.


- One single (no cluster) fire damper is located at a minimum distance ( $\leq$  75 mm) from a wall or floor/ceiling.



12

12. Seal the rest of the opening with 2 layers of 50 mm-thick coated rigid mineral wool panels (see above).

### 13




Installation in rigid floor, sealing with rigid rock wool boards with coating


The product was tested and approved in:

Range	Wall type		Sealing	Classification
Ø 100-315 mm	Rigid floor	Aerated concrete $\geq$ 150 mm	Stone wool + coating $\ge 140 \text{ kg/m}^3 + \text{coated casing}$	El 120 (h <sub>o</sub> i $\leftrightarrow$ o) S - (300 Pa)
Ø 100-315 mm	Rigid floor	Aerated concrete $\geq$ 150 mm	Stone wool + coating $\geq 140 \text{ kg/m}^3$	El 90 (h <sub>o</sub> i ↔ o) S - (300 Pa)

2

4






1. The opening around the damper is sealed with 2 layers of 50 mm-thick mineral wool panels with fire resistant coating on one side (type PROMASTOP-CB 50 / PROMASTOP-CB/CC 50 / HILTI CFS-CT B).

3


1




PROMASTOPE/CC HILTICFS-SACE

3. The joints on these 2 layers must be installed staggered and covered all around the edge with coating (type PROMASTOP-E / PROMASTOP-CC / HILTI CFS-S-ACR).

7




5. For El 120 S, the casing of the fire damper must be covered with a layer (> 1 mm) of coating (type PROMASTOP E / PROMASTOP CC / HILTI CFS-CT).




7. The damper does not need to be centered in the opening (with max dimensions fire damper + 600 mm). The maximal distance between the damper and the edge of the opening is 400 mm.

9




9. For details, please refer to 'Installation in flexible and rigid wall, sealing with rigid rock wool boards with coating'



6

8




8. The dampers can be installed at a minimum distance (≥ 30 mm) from an adjacent wall or from another damper.

TEST!

Installation remote from the wall, sealing and insulation with rigid rock wool boards with coating


### The product was tested and approved in:



3. An opening with maximal dimensions "A" is made in the wall. For a light partition wall, follow the wall assembly under "Installation in flexible or rigid wall - Sealing with fire resistant rigid panels of stone wool".

4. The fire damper is mounted remote from the wall at the end of a metal duct. The fire damper is supported by a clamping ring of the same diameter as the damper, held in place by threaded rods "C". The duct is supported every 1500 mm. The suspensions consist of threaded rods "C" and U-shaped steel profiles "D". A free space of maximum 25 mm is left between the threaded rods and the vertical walls of the stone wool casing "B".

7




5. The opening around the duct is sealed with stone wool plates type Promastop CB(/CC) / Hilti CFS-CT B ("G"). The edges are sealed and maintained in place with PROMASTOP E / PROMASTOP CC / HILTI CFS-S ACR coating.

6. The duct is covered over its entire length with stone wool plates "G". To adhere to the duct, the plates are completely coated on one side with fire resitant coating and affixed to the duct with steel screws and washers "E".

The damper casing is covered with stone wool plates "G" for 171 mm. A free space should be left around the mechanism to guarantee access.

The joints between the plates, between the wall and the plates as well as the screws and washers are filled with coating PROMASTOP E / PROMASTOP CC / HILTI CFS-S ACR. $\mu$ 




7. An additional stone wool panel type "G", coated with PROMASTOP E / PROMASTOP CC / HILTI CFS-S ACR, is applied in the opening between the damper casing and the stone wool panels.


### 8

6







9. The dampers can be installed at a minimum distance from an adjacent wall/floor or from another damper.




11. Apply rigid stone wool panels (150 kg/m<sup>3</sup>) to a depth of 250 mm (wall thickness + additional at the rear side of the wall) to seal the opening at the side with minimal distances. When the distance between the damper and the wall is greater than 75 mm, the sealing of the opening between the damper and the wall is carried out according to the pre-existing classification.






14. Apply rigid stone wool panels (150 kg/m<sup>3</sup>) to a depth of 150 mm to seal the opening at the side with minimal distances.



10


12

14




13

Installation remote from the wall, sealing with mortar and insulation with rigid rock wool boards with coating The product was tested and approved in:




3. An opening with maximal dimensions "A" is made in the wall.

4. The fire damper is mounted remote from the wall at the end of a metal duct. The fire damper is supported by a clamping ring of the same diameter as the damper, held in place by threaded rods "C". The duct is supported every 1500 mm. The suspensions consist of threaded rods "C" and U-shaped steel profiles "D". A free space of maximum 25 mm is left between the threaded rods and the vertical walls of the stone wool casing "B". 7




5. The opening around the duct is sealed with standard mortar.



6. The duct is covered over its entire length with stone wool plates "G". To adhere to the duct, the plates are completely coated on one side with fire resitant coating and affixed to the duct with steel screws and washers "E".

The damper casing is covered with stone wool plates "G" for 171 mm. A free space should be left around the mechanism to guarantee access.

The joints between the plates, between the wall and the plates as well as the screws and washers are filled with coating PROMASTOP E / PROMASTOP CC / HILTI CFS-S ACR.



7. An additional stone wool panel type "G", coated with PROMASTOP E / PROMASTOP CC / HILTI CFS-S ACR, is applied in the opening between the damper casing and the stone wool panels.

### 8

6





### Installation remote from the wall + GEOFLAM

### The product was tested and approved in:


Range	Wall type		Sealing	Classification
Ø 100-315 mm	Rigid wall	Aerated concrete $\geq$ 100 mm	Galvanised duct + GEOFLAM® F 45 mm + mortar	El 120 ( $v_e i \leftrightarrow o$ ) S - (500 Pa)
Ø 100-315 mm	Rigid wall	Aerated concrete ≥ 100 mm	Galvanised duct + GEOFLAM® Light 35 mm + morta	r El 120 (v <sub>e</sub> i ↔ o) S - (500 Pa)
	1			El1205 A ≥Dn+80 3 (Dn+125) x(Dn+125)

4






3




3. An opening with maximal dimensions "A" is made in the wall.

4. The fire damper is mounted remote from the wall at the end of a metal duct. The duct is supported every 1000 mm. The suspensions consist of threaded rods "C" and U-shaped steel profiles "D". A free space of maximum 25 mm is left between the threaded rods and the vertical walls of the casing "B".









5. The opening around the duct is sealed with standard mortar. The duct is covered with 45 mm thick GEOFLAM F plates or 35 mm thick GEOFLAM Light plates "G".

The plates adhere to each other with glue and fibrous plaster "E". The damper casing is also covered on a length of 171 mm.



7. The threaded rods are covered with U-shaped plates of GEOFLAM (Ø 90 mm) and affixed with glue and fibrous plaster. The profiles are covered with U-shaped shells GEOFLAM 100 x 60 mm, which are affixed to the underside of the shaft with GEOCOL (GEOSTAFF) cement plaster.




9. The dampers can be installed at a minimum distance from an adjacent wall/floor or from another damper.

6

8


10



6. The GEOFLAM F / GEOFLAM Light plates stop at a distance of 20 mm from the wall. The free space is filled with fibrous plaster.

The same filling is applied to seal off the connection between the GEOFLAM F plates and the damper casing.






5


7


9


## Installation



11. Apply rigid stone wool panels  $(150 \text{ kg/m}^3)$  to a depth of 250 mm (wall thickness + additional at the rear side of the wall) to seal the opening at the side with minimal distances.







14. Apply rigid stone wool panels (150 kg/m<sup>3</sup>) to a depth of 150 mm to seal the opening at the side with minimal distances.



#### Installation in rigid wall with collar for surface-mount 1s

### The product was tested and approved in:

Range		Wall	type			Sealing	Classification
R120-1S Ø 100	-315 mm	Rigid	wall		Aerated concrete ≥ 100 mm	Not applicable	El 120 (v <sub>e</sub> i $\leftrightarrow$ o) S - (500 Pa)
					2		
	ØDn	<b>1</b> s	Ød	ø			
	100	279	160	180			
	125	299	180	200			
	160	339	220	240			
	200	374	255	275		X	
	250	419	300	320			12 10
	315	474	355	375			
	← 6x(05x70)	- ()				TEST!	
1							

5. The dampers can be installed at a minimum distance from an adjacent wall or from another damper.

#### Installation in flexible wall with collar for surface-mount 1s


#### The product was tested and approved in:

Range		Wall	type			Sealing	Classification
CR120-15 Ø 100-3	15 mm	Flexib	le wall	Metal st Type F (	uds gypsum plasterboard EN 520) ≥ 100 - ≤ 125 mm	Not applicable	EI 120 ( $v_e i \leftrightarrow o$ ) S - (500 Pa)
1					2		1
	ØDn	<b>1</b> s	Ød	ø			
	100	279	160	180			
	125	299	180	200			
	160	339	220	240			<u></u>
	200	374	255	275		X	
	250	419	300	320			t to may
	315	474	355	375			İ
3			≤ 625 mm	2x12,5 mm F (EN520) →	4		ur u
5	() () ≥ 40 kg/m	2x12,5 F (EN52			P ]	6 x (Ø5 x 70 mm)	100≤ x ≤ 125 ★ ★
		ST B3 mm 345 mm					


6. The dampers can be installed at a minimum distance from an adjacent wall or from another damper.


### Installation 4

#### Inspection of the damper



1. Remove the air-tight plug from the damper.





2. Insert the camera of the endoscope (for example Inspecam Rf-t) through the opening and inspect the inside of the damper.

3. After inspection, replace the air-tight plug thoroughly on the damper opening. The position is crucial in order to maintain the air-tightness of the fire damper.

#### Maintenance

- No specific maintenance required.
- Schedule at least 2 visual checks each year.
- Remove dust and all other particles before use.
- Follow local maintenance regulations (i.e. BS9999 Annex V; NF S 61-933) and EN13306.
- Read the maintenance instructions on our website:
- https://www.rft.be/assets//PIM/DOCUMENTS/BROCHURE%20KITS/BRO\_K139\_MAINTENANCE\_C.pdf
- Use the damper at up to 95% humidity, non-condensing.
- The fire damper can be cleaned with a dry or slightly damp cloth. It is forbidden to use abrasive cleaners or mechanical cleaning techniques (brush).

#### **Operation and mechanisms**



#### MFUS(P) Mechanism with fusible link

The operating mechanism MFUS(P) automatically unlocks the blade when the temperature in the duct exceeds 72°C. The damper can also be unlocked and reset manually.

- 1. unlocking button
- 2. resetting handle
- 3. cable entrance



#### Options - at the time of order

FDCU	Limit switch 'open/closed'

#### Unlocking

- **manual unlocking**: press the unlocking button (1).
- **automatic unlocking**: the fusible link melts when the temperature reaches 72°C in the duct.
- remote unlocking: n/a

#### Resetting

- manual resetting: turn the resetting handle (2) 90° clockwise (or use a 10 mm hex key).
- **motorised resetting**: n/a

#### Caution:

A The mechanism may never be tested on its own, without being attached to the damper. Such a test might damage the mechanism or the operator might be injured.

ONE Spring return actuator for remote control

The spring-return actuator ONE is designed to easily operate Rf-t fire dampers of all sizes, automatically or remotely. Five models are available, 24 or 230 volt, with FDCU or FDCB position switches; and 24 volt with plug (ST).

- 1. unlocking button
- 2. blade position indicator
- 3. LED
- 4. battery compartment to reset motor
- 5. plug (ST)



#### Unlocking

- **manual unlocking**: shortly press the unlocking button (1) once.
- automatic unlocking: the fusible link reacts as soon as the temperature in the duct reaches 72°C.
- **remote unlocking**: by interrupting the power supply.

#### Resetting

- manual resetting: open the battery compartment (4) and press a 9V battery against the contact springs. Hold this position until the LED (3) emits a continuous light. Check whether the indicator (2) shows that the damper blade is in the open position. Remove the battery, the LED fades away. Close the battery compartment.
- motorised resetting: switch off the power supply for at least 5 sec. Power the actuator (respect the prescribed voltage) for at least 75 sec. The resetting stops automatically when the end of range is reached (damper open).

#### Caution:

- A If the LED (3) flickers fast (3x/sec.), the battery is discharged: use a new battery.
- A If the LED (3) flickers slowly (1x/sec), the resetting is in progress.
- A If the LED (3) is continuously on, the resetting is complete and the motor is powered.
- A If the actuator detects voltage on the power cable, a brief contact of the battery is enough to start the resetting process.
- A The power supply of this actuator cannot be individually replaced. If the cable is damaged, the whole unit must be discarded and replaced.
- ▲ The housing of the mechanism contains a temperature sensor. When the temperature in the housing exceeds 72°C, the mechanism unlocks. The LED flashes twice per second. When the temperature drops below 72°C, the mechanism can only be reset in a motorised manner after a manual reset (with a battery).
- A The end of range switches need 1 second after operation to adopt a stable position.
- A Make sure the thermal trigger device is present in the actuator. The actuator might not function properly if this is not the case.

		prod. <	1/7/2015		prod. ≥ 1/7/2015			
	CR60(1s)	CU-LT	CR2≤400	CR2>400	CR60(1s)	CU-LT	CR2≤400	CR2>400
	CR120	CU-LT-1s	CU2≤1200	CU2>1200	CR120(1s)	CU-LT-1s	CU2≤1200	CU2>1200
Kit ONE	•	•	•		•	•	•	•

**O**<sup>\*</sup>


ONE-X Spring return actuator with integrated communication module.

The ONE-X is a spring return actuator with integrated communication module designed to simply operate Rf-t fire dampers of all sizes, automatically or remotely. The ONE-X is available in two versions: 24 V and 230 V.

#### 1. unlocking button

- 2. blade position indicator
- 3. LED red: status
- 4. battery compartment
- 5. LED blue: communication
- 6. LED orange: error message
- 7. supply
- 8. bus cable

#### Options - at the time of order



**ONE-X CN** Connectors for the bus cables and the power cable.

#### Unlocking

- **manual unlocking**: shortly press the unlocking button (1) once.
- automatic unlocking: the fusible link reacts as soon as the temperature in the duct reaches 72°C.
- remote unlocking: via ZENiX controller

#### Resetting

- manual resetting: Open the battery compartment (4) and press a 9V battery against the contact springs. Hold this position until the red LED (3) emits a continuous light. Control whether the indicator (2) indicates that the damper blade is open. Remove the battery. Close the battery compartment.
- motorised resetting: via ZENiX controller. By applying voltage during first use.

#### Caution:

- ▲ If the ONE-X detects voltage on the power cable, a brief contact of the battery is enough to start the resetting process, provided the ZENiX controller has sent the damper to open position or the ONE-X is being operated for the first time.
- A The power supply of this actuator cannot be individually replaced. If the cable is damaged, the whole unit must be discarded and replaced.
- ▲ The housing of the mechanism contains a temperature sensor. When the temperature in the housing exceeds 72°C, the mechanism unlocks. The LED flashes twice per second. When the temperature drops below 72°C, the mechanism can only be reset in a motorised manner after a manual reset (with a battery).
- **A** The end of range switches need 1 second after operation to adopt a stable position.

#### Safety regulations:

- A Do not use the ONE-X for any application other than the specified applications, in particular not in aircraft or other airborne vehicles.
- The company that purchases and/or installs the ONE-X is fully responsible for the correct operation of the entire system. Only authorised specialists may perform the installation. All rules and regulations, including statutory regulations, must be observed during installation.
- A This device contains electrical or electronic components and must not be disposed of as household waste. All locally applicable regulations and requirements must be strictly observed.

BFL(T) Remotely controlled spring return actuator

The spring return actuator BFL(T) is specially designed to remotely control fire dampers. The BFL(T) model is intended for fire dampers with smaller dimensions ( $\emptyset \le 400$  mm or W+H  $\le 1200$  mm/1400 mm for CU-LT, CU-LT-1s).

- 1. locking button
- 2. plug (ST)
- 3. access for manual resetting
- 4. thermo-electric tripping device (T)



#### Options - at the time of order

SN2 BFL/BFN Auxiliary limit switch 'open/closed'

#### Unlocking

- manual unlocking: place the locking button on "unlock". (In case of BFLT: the damper can alternatively be unlocked by pushing the "test" button on the thermo-electric fuse)
- **automatic unlocking**: the thermo-electric fuse reacts as soon as the temperature reaches 72°C (type BFLT).
- remote unlocking: by interrupting the power supply.

#### Caution:

A The thermo-electric fuse will not move the damper into its safety position (when the temperature reaches 72°C) if the motor is not powered.

#### Resetting


- **manual resetting**: turn the enclosed handle anti-clockwise. To block the motor, place the locking button on "lock"
- motorised resetting: switch off the power supply for at least 10 seconds. Supply the actuator (respect the prescribed voltage) for at least 75 seconds. The resetting stops automatically when the end of range is reached (damper open) it takes about 60 seconds to reset the damper or when the power supply is interrupted.


#### Caution:

- A Do not use a drill or powered screwdriver.
- A Stop as soon as the motor is completely rearmed (end of range).

		prod. <	1/7/2015			prod. ≥ 1/	7/2015	
	CR60(1s)	CU-LT	CR2≤400	CR2>400	CR60(1s)	CU-LT	CR2≤400	CR2>400
	CR120	CU-LT-1s	CU2≤1200	CU2>1200	CR120 (1s)	CU-LT-1s	CU2≤1200	CU2>1200
Kit BFL					•	•	•	
Kit BFN	•	•	•					•
Kit BF				•				

**Electrical connection** 





**DC :** Switch open position fire damper **FC :** Switch closed position fire damper


**DC :** Switch open position fire damper **FC :** Switch closed position fire damper

MEC	Nominal voltage motor	Nominal voltage magnet	Power consumption (stand-by)	Power consumption (operating)	Standard switches
MFUS	N/A	N/A	N/A	N/A	1mA1A, DC 5VAC 48V
ONE T 24 FDCU	24 V AC/DC (-10/+20%)	N/A	0,28W	4,2W	1mA1A 60V
ONE T 230 FDCU	230 V AC (-15/+15%)	N/A	0,57W	4,2W	1mA1A 60V
ONE T 24 FDCU ST	24 V AC/DC (-10/+20%)	N/A	0,28W	4,2W	1mA1A 60V
ONE T 24 FDCB	24 V AC/DC (-10/+20%)	N/A	0,28W	4,2W	1mA1A 60V
ONE T 230 FDCB	230 V AC (-15/+15%)	N/A	0,57W	4,2W	1mA1A 60V
ONE-X 24	24 V AC/DC (-10/+20%)	N/A	0,28W	4,2W	
ONE-X 230	230 V AC (-15/+15%)	N/A	0,57W	4,2W	
BFL24	24 V AC/DC	N/A	0,7W	2,5W	1mA3A, AC 250V
BFL230	230 V AC	N/A	1,1W	3,5W	1mA3A, AC 250V
BFL24-ST	24 V AC/DC	N/A	0,7W	2,5W	1mA3A, AC 250V
BFLT24	24 V AC/DC	N/A	0,8W	2,5W	1mA3A, AC 250V
BFLT230	230 V AC	N/A	1,4W	4W	1mA3A, AC 250V
BFLT24-ST	24 V AC/DC	N/A	0,8W	2,5W	1mA3A, AC 250V

6

6

grey



**DC**: Switch open position fire damper **FC**: Switch closed position fire damper

MEC	Resetting time motor	Running time spring	Noise level motor	Noise level spring	Cable supply / control	Cable auxiliary switch	Protection class
MFUS	N/A	1 s	N/A	N/A			IP 42
ONE T 24 FDCU	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup>	1 m, 6 x 0.75 mm <sup>2</sup>	IP 54
ONE T 230 FDCU	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup>	1 m, 6 x 0.75 mm <sup>2</sup>	IP 54
ONE T 24 FDCU ST	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup>	1 m, 6 x 0.75 mm <sup>2</sup>	IP 54
ONE T 24 FDCB	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup>	(2x) 1 m, 6 x 0,75 mm <sup>2</sup>	IP 54
ONE T 230 FDCB	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup>	(2x) 1 m, 6 x 0,75 mm <sup>2</sup>	IP 54
ONE-X 24	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)			IP 54
ONE-X 230	< 75 s (cabled) / <85 s (battery)	< 30 s	< 64 dB (A)	< 67 dB (A)			IP 54
BFL24	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.34 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54
BFL230	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54
BFL24-ST	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54
BFLT24	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.34 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54
BFLT230	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54
BFLT24-ST	< 60 s	20 s	< 43 dB (A)	< 62 dB (A)	1 m, 2 x 0.75 mm <sup>2</sup> (halogen-free)	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)	IP 54

# 48 Weights

Weights

#### CR120 + MFUS

ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	1,6	1,8	2,0	2,1	2,5	2,6	3,3	4,1	4,2	
R120 + ONE T	/ ONE-X									
ØDn (mm)	100	125	150	160	180	200	250	300	315	
kg	2,8	3,0	3,2	3,3	3,7	3,8	4,5	5,3	5,4	
R120 + BFL										
ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	2,3	2,5	2,7	2,8	3,2	3,3	4,0	4,8	4,9	
R120 + BFLT										
ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	2,4	2,6	2,8	2,9	3,3	3,4	4,1	4,9	5,0	
R120-L500 + M	MFUS									
ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	1,9	2,3	2,6	2,7	3,2	3,4	4,2	5,3	5,4	
120-L500 + 0	ONE T / OP	NE-X								
ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	3,1	3,5	3,8	3,9	4,4	4,6	5,4	6,5	6,6	
120-L500 + E	BFL									
ØDn (mm)	100	125	150	160	180	200	250	300	315	
kg	2,6	3,0	3,3	3,4	3,9	4,1	4,9	6,0	6,1	
120-L500 + E	BFLT									
ØDn [mm]	100	125	150	160	180	200	250	300	315	
kg	2,7	3,1	3,4	3,5	4,0	4,2	5,0	6,1	6,2	
R120-1S + MF	US									
ØDn [mm]	100	125	160	200	250	315				
kg	6,1	6,9	8,3	9,9	11,4	12,7				
120-1S + ON	E T / ONE-	x								
ØDn (mm)	100	125	160	200	250	315				
kg	7,3	8,1	9,5	11,1	12,6	13,9				
100 1C · DEL										
120-1S + BFL										

ØDn [mm]	100	125	160	200	250	315		
kg	6,8	7,6	9,0	10,6	12,1	13,4		



CR120-1S + BFLT

ØDn [mm]	100	125	160	200	250	315		
kg	6,9	7,7	9,1	10,7	12,2	13,5		

CR120-1S-L500 + MFUS

ØDn [mm]	100	125	160	200	250	315		
kg	6,3	7,2	9,1	10,5	12,1	13,6		

#### CR120-1S-L500 + ONE T / ONE-X

ØDn [mm]	100	125	160	200	250	315		
kg	7,5	8,4	10,3	11,7	13,3	14,8		

#### CR120-1S-L500 + BFL

ØDn [mm]	100	125	160	200	250	315		
kg	7,0	7,9	9,8	11,2	12,8	14,3		

#### CR120-1S-L500 + BFLT

ØDn [mm]	100	125	160	200	250	315		
kg	7,1	8,0	9,9	11,3	12,9	14,4		

#### Selection data

Δp [Pa	$] = \zeta^* v$	v <sup>2</sup> *0,6								
ØDn [mm]	100	125	150	160	180	200	250	300	315	
ζ[-]	0,87	0,73	0,6	0,56	0,48	0,42	0,29	0,19	0,18	

#### Example

Data Dn = 250 mm, v = 5 m/s Calculation  $\Delta p = 0.29 * (5 m/s)^2 * 0.6 = 4.35$  Pa 

	315	300	250	200	180	160	150	125	100	ØDn [mm]
	0,0672	0,0605	0,0407	0,0248	0,0195	0,0149	0,0128	0,0082	0,0047	Sn [m²]
	86,82	86,18	83,52	79,58	77,41	74,79	71,43	68,23	61,06	Sn [%]
45 d	1.797,00	1.606,00	1.043,00	616,00	482,00	363,00	312,00	201,00	117,00	Q [m³/h]
4J U	4,34	5,00	6,00	7,41	8,00	8,45	9,00	9,03	9,01	Δp [Pa]
40 d	1.248,00	1.115,00	725,00	428,00	335,00	252,00	217,00	139,00	81,00	Q [m <sup>3</sup> /h]
4V U	2,09	2,00	2,89	3,57	4,00	4,07	4,00	4,35	4,35	Δp [Pa]
35 d	866,00	774,00	503,00	297,00	232,00	175,00	151,00	97,00	56,00	Q [m³/h]
0 <b>0</b> u	1,01	1,00	1,39	1,72	2,00	1,97	2,00	2,10	2,10	Δp [Pa]
30 d	602,00	538,00	349,00	206,00	161,00	121,00	105,00	67,00	39,00	Q [m³/h]
JUU	0,49	1,00	0,67	0,83	1,00	0,95	1,00	1,01	1,01	Δp [Pa]
25 d	418,00	374,00	243,00	143,00	112,00	84,00	73,00	47,00	27,00	Q [m³/h]
23 u	0,23	0,00	0,32	0,40	0,00	0,46	0,00	0,49	0,49	Δp [Pa]

CR120 - CR120-L500 - A-weighted sound power level in the duct

Every air flow lower than the above mentioned maximum value, will meet the listed A-weighted sound power level for the respective dimension.

CR120-1S - CR120-1S-L500 - A-weighted sound power level in the duct

ØDn [mm]	100	125	160	200	250	315
Sn [m²]	0,0047	0,0082	0,0149	0,0248	0,0407	0,0672
Sn [%]	61,06	68,23	74,79	79,58	83,52	86,82
Q [m³/h]	117,00	201,00	363,00	616,00	1.043,00	1.797,00
Δp [Pa]	9,01	9,03	8,45	7,41	6,00	4,34
Q [m³/h]	81,00	139,00	252,00	428,00	725,00	1.248,00
Δp [Pa]	4,35	4,35	4,07	3,57	2,89	2,09
Q [m³/h]	56,00	97,00	175,00	297,00	503,00	866,00
Δp [Pa]	2,10	2,10	1,97	1,72	1,39	1,01
Q [m <sup>3</sup> /h]	39,00	67,00	121,00	206,00	349,00	602,00
Δp [Pa]	1,01	1,01	0,95	0,83	0,67	0,49
Q [m <sup>3</sup> /h]	27,00	47,00	84,00	143,00	243,00	418,00
Δp [Pa]	0,49	0,49	0,46	0,40	0,32	0,23

Every air flow lower than the above mentioned maximum value, will meet the listed A-weighted sound power level for the respective dimension.

#### **Correction factor AL**

To obtain the sound power level for the octave midband: LW oct =  $\Delta L$  + Lwa

[Hz]	63	125	250	500	1000	2000	4000	8000
2 - 4 m/s	24	7	-6	-16	-23	-26	-25	-18
6 - 8 m/s	20	10	0	-6	-10	-14	-21	-24
10 - 12 m/s	14	6	0	-4	-6	-9	-13	-19

**Sample order** 

CR120 200	MFUS FDCU
1 2	3 4
1. product 2. diameter	

- 3. mechanism type
- 4. option: unipolar end of range switch

#### **Approvals and certificates**

All our dampers are submitted to a number of tests by official test institutes. Reports of these tests form the basis for the approvals of our dampers.



The NF-label guarantees: conformity with the standard NF S 61-937 Parts 1 and 5: "Systèmes de Sécurité Incendie Dispositifs Actionnés de Sécurité"; conformity with the national decree of March 22, 2004, changed on 14 March 2011 for the classification of fire resistance; the values of the characteristics mentioned in this document. Organisme Certificateur: AFNOR Certification, 11 Rue Francis de Pressensé, F93571 La Plaine Saint-Denis Cedex; Website: http://www.afnor.org http://www.marque-nf.com; Phone: +33 (0)1.41.62.80.00, Fax: +33 (0)1.49.17.90.00, Email: certification@afnor.org